# Combined SHIRPA and Dysmorphology HR WLLA\_CSD\_003

### **Purpose**

SHIRPA and dysmorphology were originally always separate assessments. However they have recently been combined as assessments, so that they take place at the same time.

The purpose of the assessments is to examine mice for obvious physical characteristics, behaviors and morphological abnormalities.

Descriptions include abnormal locomotion/appearance/behavior/reflex reactions.

### **Experimental Design**

• Minimum number of animals: 7M + 7F

• Age at test: Week 52

• Sex: We would expect the results of this test to show sexual dimorphism

### **Equipment**

- Viewing Jar
- SHIRPA arena
- Grid above arena
- Click Box
- Geotaxis grid
- Tube for contact righting
- Photo and/or video camera

### **Procedure**

- 1. Allow the mice to acclimatise to the phenotyping room for a period of 30 minutes prior to testing.
- 2. Throughout the test note any vocalisation, aggression, salivation or unexpected behaviours.
- 3. During this test, note any unexpected dysmorphological characteristics (morphological irregularities are recorded by video sequences or photos).
- 4. Place the mouse in a clear cylinder over a wire grid and observe for activity and tremors.
- 5. Transfer the mouse out of the cylinder by removing the metal plate/grid whilst positioning 30cm over an arena and record the transfer arousal.

- 6. Record the number of 10cm<sup>2</sup> squares the mouse moves into in the first 30 seconds in the arena (locomotor activity).
- 7. Allow the mouse to move freely around the arena whilst being observed for gait and tail elevation.
- 8. Hold the click box approximately 30cm above the arena and press the button, record the response of the mouse.
- 9. Pick up the mouse by the tail and observe for limp grasping and trunk curl. Trunk curl must only be recorded if the mouse curls forward without twisting its body, bending to one side is not scored as a trunk curl.
- 10. Place the mouse in a small transparent tube. Turn the tube quickly so the mouse is fully upside down and record if the mouse rights itself.
- 11. Record any vocalisation and/or aggression which were observed throughout the entire test

### **Notes**

- 1. If wiping down with ethanol prior to the use of equipment, make sure no ethanol residue remains as the ethanol may affect the behaviour of the animals.
- 2. The validity of results obtained from behavioural phenotyping is largely dependent on methods of animal husbandry. It is important that individuals following this procedure are experienced and aware of the animal's welfare, and is familiar with the animal being tested, in order to reduce the anxiety levels of the animal prior to testing.
- 3. The majority of mouse behavioural studies are age/sex/strain dependent. It is important to keep these parameters comparable throughout a single experiment.
- 4. Environmental factors may contribute to the levels of anxiety within the mouse. The temperature, humidity, ventilation, noise intensity and light intensity must be maintained at levels appropriate for mice. It is essential that the mice be kept in a uniform environment before and after testing to avoid anomalous results being obtained.
- 5. It is recommended that all phenotyping experimentation is conducted at approximately the same time of day because physiological and biochemical parameters change throughout the day.
- 6. When a number of mice are tested continuously, residual odours from the equipment used in the preceding test may affect the test results. The floor and walls of the arena, ruler, and metal net should be wiped clean before introducing the next mouse. To prevent infection, the equipment should be washed with water at the completion of the day's tests. Some specific pathogen-free facilities use ultraviolet irradiation when tests are not being performed. Care needs to be taken, however, to ensure that ultraviolet irradiation does not crack any acrylate equipment covered with residual alcohol.

### **Parameters and Metadata**

Skin color - back paws HRWLLA\_CSD\_060\_001 | v1.0

simpleParameter

Options: Not as expected, As	s expected,		
Forelimbs - size HR simpleParameter	WLLA_CSD_019_001   v1.0		
Req. Analysis: false	Req. Upload: true	Is Annotated: true	
Options: Both forelimbs - decreased, One forelimb only - increased, One forelimb only - decreased, Both forelimbs - increased, As expected,			
Skin texture - whole body HRWLLA_CSD_062_001   v1.0 simpleParameter			
Req. Analysis: false	Req. Upload: true	Is Annotated: true	
Options: As expected, Not as	s expected,		

### Coat - color - back HRWLLA\_CSD\_005\_001 | v1.0

simpleParameter

Req. Analysis: false Req. Upload: true Is Annotated: true

Options: Not as expected, As expected, No data,

Hindlimb nail - length HRWLLA_CSD_053_002   v2.0 simpleParameter			
Req. Analysis: false	Req. Upload: true	Is Annotated: true	
<b>Options:</b> Both hindlimbs - increased length, One hindlimb - decreased length, No data, As expected, One hindlimb - increased length, Both hindlimbs - decreased length,			
Snout size HRWLLA_simpleParameter	CSD_028_001   v1.0		
Req. Analysis: false	Req. Upload: true	Is Annotated: true	
Options: Decreased, As expected, Increased,			
Experimenter ID HRWLLA_CSD_081_001   v1.0 procedureMetadata			
Req. Analysis: false	Req. Upload: true	Is Annotated: false	

Lower teeth appearance HRWLLA\_CSD\_070\_001 | v1.0

Req. Analysis: false Req. Upload: true Is Annotated: true Options: Not as expected, As expected, No data, Tremor HRWLLA\_CSD\_030\_001 | v1.0 simpleParameter Req. Analysis: false Req. Upload: true Is Annotated: true **Options:** Present, Absent, Locomotor activity HRWLLA\_CSD\_032\_001 | v1.2 simpleParameter Req. Analysis: false Req. Upload: true Is Annotated: true

Unit Measured: Squares crossed

### Vibrissae - appearance HRWLLA\_CSD\_024\_001 | v1.0

simpleParameter

Req. Analysis: false Req. Upload: true Is Annotated: true

**Options:** Not as expected, No data, As expected,

Trunk curl HRWLLA_C simpleParameter	SD_038_001   v1.0	
Req. Analysis: false	Req. Upload: true	Is Annotated: true
Options: No data, Absent, Pre	esent,	
Head bobbing HRWL simpleParameter	LA_CSD_080_001   v1.0	
Req. Analysis: false	Req. Upload: true	Is Annotated: true
Options: Present, Absent,		
Tail - length HRWLLA simpleParameter	_CSD_002_001   v1.1	
Req. Analysis: false	Req. Upload: true	Is Annotated: true
Options: Long, No data, Shor	t, As expected,	

------

### Transfer arousal HRWLLA\_CSD\_031\_001 | v1.2

simpleParameter

Req. Analysis: false Req. Upload: false Is Annotated: false

**Options:** As expected, Extended freeze, Immediate movement,

.....

### Images HRWLLA\_CSD\_085\_001 | v1.1

seriesMediaParameter

Req. Analysis: false Req. Upload: false Is Annotated: false

### Tail elevation HRWLLA CSD 034 001 | v1.2

simpleParameter

Req. Analysis: false Req. Upload: false Is Annotated: false

**Options:** No data, Straub / elevated tail, As expected, Dragging,

.....

### Skin texture - snout HRWLLA\_CSD\_063\_001 | v1.0

simpleParameter

Req. Analysis: false Req. Upload: true Is Annotated: true

**Options:** As expected, Not as expected,

Genitalia - size HRWLLA CSD 072 001 | v1.1 simpleParameter Req. Analysis: false Req. Upload: true Is Annotated: true **Options:** No data, Not as expected, As expected, Number of days since cage changed HRWLLA\_CSD\_084\_001 | v1.1 procedureMetadata Req. Analysis: false Req. Upload: false Is Annotated: false Hindlimb nail - shape HRWLLA\_CSD\_055\_002 | v2.0 simpleParameter Req. Analysis: false Req. Upload: true Is Annotated: true **Options:** One hindlimb - not as expected, No data, Both hindlimbs - not as expected, As expected,

Req. Analysis: false Req. Upload: true Is Annotated: true

**Options:** One forelimb - decreased number, Both forelimbs - decreased number, As expected, Both forelimbs - increased number, One forelimb - increased number,

### Coat - hair texture / appearance - abdomen HRWLLA\_CSD\_016\_

001 | v1.0

simpleParameter

Reg. Analysis: false Reg. Upload: true Is Annotated: true

Options: As expected, No data, Not as expected,

.....

### Vibrissae - presence HRWLLA\_CSD\_023\_001 | v1.0

simpleParameter

Req. Analysis: false Req. Upload: true Is Annotated: true

**Options:** As expected, Not as expected,

Hindpaw - size HRWLLA\_CSD\_041\_002 | v2.0

simpleParameter

Req. Analysis: false Req. Upload: true Is Annotated: true

Options: Both hindpaws - decreased, As expected, One hindpaw - increased,

Both hindpaws - increased, One hindpaw - decreased,

### Hindlimb nail - number HRWLLA\_CSD\_051\_002 | v2.0

simpleParameter

Req. Analysis: false Req. Upload: true Is Annotated: true

Options: Both hindlimbs - increased number, As expected,

Both hindlimbs - decreased number, One hindlimb - increased number,

One hindlimb - decreased number, No data,

### Coat - hair distribution - abdomen HRWLLA\_CSD\_013\_001 | v1.0

simpleParameter

Req. Analysis: false Req. Upload: true Is Annotated: true

**Options:** Not as expected, As expected,

\_\_\_\_\_

### Mouth morphology HRWLLA\_CSD\_074\_001 | v1.0

simpleParameter

Options: Not as expected, As expected,			
Number of animals procedureMetadata	in cage HRWLLA_CSD_	_083_001   v1.2	
Req. Analysis: false	Req. Upload: true	Is Annotated: false	
<b>Hindlimbs - size</b> HR simpleParameter	WLLA_CSD_022_001   v1.1		
Req. Analysis: false	Req. Upload: true	Is Annotated: true	
<b>Options:</b> As expected, Both hindlimbs - decreased, One hindlimb only - increased, Both hindlimbs - increased, One hindlimb only - decreased,			
Gait HRWLLA_CSD_033_ simpleParameter	001   v1.0		
Req. Analysis: false	Req. Upload: true	Is Annotated: true	
Options: Fluid movement, Lac	ck of fluidity in movement,		

### Genitalia - morphology HRWLLA\_CSD\_073\_001 | v1.1

simpleParameter

Req. Analysis: false Req. Upload: true Is Annotated: true

**Options:** As expected, No data, Not as expected,

.....

### Forelimb nail - number HRWLLA CSD 050 002 | v2.0

simpleParameter

Req. Analysis: false Req. Upload: true Is Annotated: true

Options: One forelimb - decreased number, No data, As expected,

Both forelimbs - increased number, Both forelimbs - decreased number,

One forelimb - increased number,

### Unexpected behaviors HRWLLA\_CSD\_037\_001 | v1.0

simpleParameter

Req. Analysis: false Req. Upload: true Is Annotated: true

Options: Retropulsion, Other, None, Jumping, Circling,

Skin color - front paws HRWLLA\_CSD\_059\_001 | v1.0

Req. Analysis: false	Req. Upload: true	Is Annotated: true		
Options: As expected, Not as	expected,			
Teeth presence HRV simpleParameter	WLLA_CSD_068_001   v1.0			
Req. Analysis: false	Req. Upload: true	Is Annotated: true		
Options: Not as expected, As	Options: Not as expected, As expected,			
Skin texture - tail HRWLLA_CSD_067_001   v1.0 simpleParameter				
Req. Analysis: false	Req. Upload: true	Is Annotated: true		
Options: As expected, Not as expected, No data,				
Hindlimb digit - nu	mber HRWLLA CSD 045	002 Lv2 0		

simpleParameter

**Options:** Both hindlimbs - decreased number, Both hindlimbs - increased number, One hindlimb - decreased number, As expected, One hindlimb - increased number,

.....

## Coat - hair texture / appearance - back HRWLLA\_CSD\_014\_001 | v1 .0

simpleParameter

Req. Analysis: false Req. Upload: true Is Annotated: true

**Options:** No data, Not as expected, As expected,

### Hindlimb digit - size HRWLLA\_CSD\_047\_001 | v1.2

simpleParameter

Req. Analysis: false Req. Upload: true Is Annotated: true

Options: One hindlimb - decreased size, One hindlimb - fused,

Both hindlimbs - increased size, As expected, Both hindlimbs - fused,

One hindlimb - increased size, Both hindlimbs - decreased size,

### Coat - color pattern - back HRWLLA\_CSD\_008\_001 | v1.0

simpleParameter

Options: Not as expected, No	data, As expected,		
Coat - hair texture	/ appearance - head	HRWLLA_CSD_015_001   v1	
Req. Analysis: false	Req. Upload: true	Is Annotated: true	
Options: Not as expected, No	data, As expected,		
Upper teeth appear	rance HRWLLA_CSD_069	_001   v1.0	
Req. Analysis: false	Req. Upload: true	Is Annotated: true	
Options: No data, As expected, Not as expected,			
Coat - color - abdo simpleParameter	<b>men</b> HRWLLA_CSD_007_	001   v1.0	

Req. Analysis: false Req. Upload: true Is Annotated: true

Options: As expected, Not as expected, No data,

Location of test HRWLLA\_CSD\_082\_001 | v1.1 procedureMetadata Req. Analysis: false Req. Upload: true Is Annotated: false Options: LAF cabinet, Open bench, Head size HRWLLA CSD 025 001 | v1.0 simpleParameter Req. Analysis: false Req. Upload: true Is Annotated: true Options: As expected, Decreased, Increased, Forepaw - shape HRWLLA\_CSD\_042\_002 | v2.0 simpleParameter Req. Analysis: false Req. Upload: true Is Annotated: true Options: As expected, One forepaw - not as expected, Both forepaws - not as expected, Req. Analysis: false Req. Upload: false Is Annotated: true

Options: No data, None, Present,

.....

### Coat - color - head HRWLLA\_CSD\_006\_001 | v1.0

simpleParameter

Req. Analysis: false Req. Upload: true Is Annotated: true

Options: No data, Not as expected, As expected,

### Vocalization HRWLLA\_CSD\_078\_001 | v1.0

simpleParameter

Req. Analysis: false Req. Upload: true Is Annotated: true

Options: As expected, Not as expected,

### Skin color - snout HRWLLA\_CSD\_057\_001 | v1.0

simpleParameter

Options: Not as expected, As expected,			
Forelimbs - positio	h HRWLLA_CSD_017_001	v1.0	
Req. Analysis: false	Req. Upload: true	Is Annotated: true	
Options: As expected, Both for	orelimbs - not as expected, One	e forelimb only - not as expected,	
Forelimbs - shape HRWLLA_CSD_018_001   v1.0 simpleParameter			
Req. Analysis: false	Req. Upload: true	Is Annotated: true	
Options: As expected, Both for	orelimbs - not as expected, One	e forelimb only - not as expected,	
Skin color - tail HRWLLA_CSD_061_001   v1.0 simpleParameter			
Req. Analysis: false	Req. Upload: true	Is Annotated: true	
Options: Not as expected, As	expected, No data,		

### Ears HRWLLA\_CSD\_027\_001 | v1.0

simpleParameter

Req. Analysis: false Req. Upload: true Is Annotated: true Options: Not as expected, As expected, Genitalia - presence HRWLLA\_CSD\_071\_001 | v1.1 simpleParameter Req. Analysis: false Req. Upload: true Is Annotated: true Options: Absent, As expected, Hindlimbs - shape HRWLLA\_CSD\_021\_001 | v1.1 simpleParameter Req. Analysis: false Req. Upload: true Is Annotated: true Options: One hindlimb only - not as expected, Both hindlimbs - not as expected, As expected,

Req. Analysis: false	Req. Upload: true	Is Annotated: true	
Options: No data, As expecte	d, Not as expected,		
Tail - thickness HRV simpleParameter	VLLA_CSD_003_001   v1.1		
Req. Analysis: false	Req. Upload: true	Is Annotated: true	
Options: As expected, Decrea	ased, Increased, No data,		
Coat - hair distribution - back HRWLLA_CSD_011_001   v1.0 simpleParameter			
Req. Analysis: false	Req. Upload: true	Is Annotated: true	
Options: Not as expected, As expected,			
Skin texture - back simpleParameter	paws HRWLLA_CSD_06	6_001   v1.0	

Req. Upload: true Is Annotated: true

Req. Analysis: false

Options: As expected, Not as	expected,	
Skin color - whole	<b>body</b> HRWLLA_CSD_056	_001   v1.0
simpleParameter		
Req. Analysis: false	Req. Upload: true	Is Annotated: true
Options: Not as expected, As	expected,	
Head morphology	HRWLLA_CSD_026_001   v1	1.0
Req. Analysis: false	Req. Upload: true	Is Annotated: true
Options: As expected, Not as	expected,	
<b>Hindpaw - shape</b> ны	RWLLA_CSD_043_002   v2.0	
Req. Analysis: false	Req. Upload: true	Is Annotated: true
Options: As expected, Both h	indpaws - not as expected, On	e hindpaw - not as expected,

### Comments (in English) HRWLLA\_CSD\_087\_001 | v1.2

simpleParameter

Req. Analysis: false Req. Upload: false Is Annotated: false Activity (body position) HRWLLA\_CSD\_029\_001 | v1.0 simpleParameter Req. Analysis: false Req. Upload: true Is Annotated: true **Options:** Inactive, As expected, Increased activity, Aggression HRWLLA\_CSD\_079\_001 | v1.0 simpleParameter Req. Analysis: false Req. Upload: true Is Annotated: true **Options:** As expected, Excessive aggression,

### Tail - presence HRWLLA\_CSD\_001\_001 | v1.1

simpleParameter

Options: Present, Absent,			
Upper lip morpholosimpleParameter	Ogy HRWLLA_CSD_075_0	01   v1.0	
Req. Analysis: false	Req. Upload: true	Is Annotated: true	
Options: Not as expected, As	expected,		
Forepaw - size HRWI simpleParameter	LLA_CSD_040_002   v2.0		
Req. Analysis: false	Req. Upload: true	Is Annotated: true	
Options: One forepaw - increased, One forepaw - decreased, Both forepaws - increased, Both forepaws - decreased, As expected,			
Coat - hair distribu	tion - head HRWLLA_C	CSD_012_001   v1.0	
Req. Analysis: false	Req. Upload: true	Is Annotated: true	
Options: Not as expected, As	expected,		

### Skin texture - front paws HRWLLA\_CSD\_065\_001 | v1.0

simpleParameter

Req. Analysis: false Req. Upload: true Is Annotated: true **Options:** As expected, Not as expected, Size of squares in arena HRWLLA\_CSD\_086\_001 | v1.0 procedureMetadata Req. Analysis: true Req. Upload: true Is Annotated: false Unit Measured: cm^2 Skin color - ear HRWLLA CSD 058 001 | v1.0 simpleParameter Req. Analysis: false Req. Upload: true Is Annotated: true Options: Not as expected, As expected,

Forelimb nail - shape HRWLLA\_CSD\_054\_002 | v2.0

Req. Analysis: false Req. Upload: true Is Annotated: true

Options: One forelimb - not as expected, No data, Both forelimbs - not as expected,
As expected,

### Lower lip morphology HRWLLA\_CSD\_076\_001 | v1.0

simpleParameter

Req. Analysis: false Req. Upload: true Is Annotated: true

Options: Not as expected, As expected,

### Forelimb digit - size HRWLLA\_CSD\_046\_001 | v1.1

simpleParameter

Req. Analysis: false Req. Upload: true Is Annotated: true

**Options:** One forelimb - decreased size, As expected, One forelimb - increased size,

One forelimb - fused, Both forelimbs - increased size, Both forelimbs - fused,

Both forelimbs - decreased size,

-----

### Hindlimb digit - shape HRWLLA\_CSD\_049\_002 | v2.0

simpleParameter

Options: Both hindlimbs - not		e hindlimb - not as expected,	
Coat - color pattern simpleParameter	n - head HRWLLA_CSD_	009_001   v1.0	
Req. Analysis: false	Req. Upload: true	Is Annotated: true	
Options: No data, Not as expe	ected, As expected,		
Skin texture - ear HRWLLA_CSD_064_001   v1.0 simpleParameter			
Req. Analysis: false	Req. Upload: true	Is Annotated: true	
Options: Not as expected, As expected,			
Limb grasp HRWLLA_simpleParameter	CSD_039_001   v1.0		
Req. Analysis: false	Req. Upload: true	Is Annotated: true	
Options: Present, Absent, No	data,		

......

### Forelimb digit - shape HRWLLA\_CSD\_048\_002 | v2.0

simpleParameter

Req. Analysis: false Req. Upload: true Is Annotated: true

Options: One forelimb - not as expected, As expected, Both forelimbs - not as expected,

### Hindlimbs - position HRWLLA\_CSD\_020\_001 | v1.1

simpleParameter

Req. Analysis: false Req. Upload: true Is Annotated: true

Options: Both hindlimbs - not as expected, As expected,

One hindlimb only - not as expected,

\_\_\_\_\_

### Forelimb nail - length HRWLLA\_CSD\_052\_002 | v2.0

simpleParameter

Req. Analysis: false Req. Upload: true Is Annotated: true

**Options:** Both forelimbs - increased length, No data, Both forelimbs - decreased length, One forelimb - decreased length, As expected, One forelimb - increased length,

\_\_\_\_\_

### Contact righting HRWLLA\_CSD\_077\_001 | v1.0

simpleParameter

Req. Analysis: false	Req. Upload: true	Is Annotated: true	
Options: No data, Present	t, Absent,		
Coat - color pattern - abdomen HRWLLA_CSD_010_001   v1.0 simpleParameter			
Req. Analysis: false	Req. Upload: true	Is Annotated: true	
Options: As expected, No	t as expected, No data,		